

Add descriptive header code here

A good reference:

<https://autogis-site.readthedocs.io/en/latest/lessons/Raster/overview.html>

```
In [3]: import rasterio
```

1. Point to the rasters and read them in:

Three layers are needed for this notebook:

GoodSlope.tif

GoodDistance.tif

FedLands_Teton.shp

```
In [4]: # Path to the good slope tif
slopef = r"C:\Users\xfour\Downloads\Lab5c_NewRasters\goodslope.tif"
```

```
In [7]: # Path to the good distance tif
trailf = r"C:\Users\xfour\Downloads\Lab5c_NewRasters\goodtrail.tif"
```

```
In [9]: sloperas = rasterio.open(slopef)

# Your turn: Now open distf and call it distras

trailras = rasterio.open(trailf)
```

```
In [10]: #Check the raster type to see that they got read in properly:
print(type(sloperas))
print(type(trailras))

<class 'rasterio.io.DatasetReader'>
<class 'rasterio.io.DatasetReader'>
```

2. Check the coordinate systems of the rasters

```
In [19]: #Print and compare the coordinate systems of each raster
print(sloperas.crs)

# Your turn: Print the distras crs
print(trailras.crs)

#Your turn: compare the 2 crs's with an if statement

if sloperas.crs == trailras.crs:
    print("Both rasters have the same CRS.")
else:
    print("The CRSs are different.")
```

```
EPSG:26912  
EPSG:26912  
Both rasters have the same CRS.
```

Since the coordinate systems are not the same, they will need to be projected. (Technically, the coordinate systems are the same, it's the datums that are different.)

```
In [20]: # Print out the file format  
print ("The GoodSlope.tif is a: " + str(sloperas.driver))
```

```
The GoodSlope.tif is a: GTiff
```

3. Read some raster information:

```
In [21]: # Read the raster stats  
import numpy as np  
array = sloperas.read()  
  
# Calculate statistics for each band  
stats = []  
for band in array:  
    stats.append({  
        'min': band.min(),  
        'mean': band.mean(),  
        'median': np.median(band),  
        'max': band.max()})  
  
# Show stats for each channel  
stats
```

```
Out[21]: [{min: 0, mean: 2.172041095453197, median: 1.0, max: 255}]
```

```
In [22]: # Your turn: Read the stats for the other raster...  
# Read the raster stats  
import numpy as np  
array = trailras.read()  
  
# Calculate statistics for each band  
stats = []  
for band in array:  
    stats.append({  
        'min': band.min(),  
        'mean': band.mean(),  
        'median': np.median(band),  
        'max': band.max()})  
  
# Show stats for each channel  
stats
```

```
Out[22]: [{min: 0, mean: 1.6559984611186835, median: 0.0, max: 255}]
```


4. Plot the data

In [26]:

```
#Let's try this visualization thing...
from rasterio.plot import show
import os
import matplotlib.pyplot as plt
%matplotlib inline


fig, ax = plt.subplots(figsize=(10, 10)) # Set the size of the figure
show(sloperas, ax=ax, title="Slope Raster Visualization") # Display the raster

plt.show()
```



```
In [27]: # Your turn: Now plot the other raster:  
fig, ax = plt.subplots(figsize=(10, 10)) # Set the size of the figure  
show(trailras, ax=ax, title="Slope Raster Visualization") # Display the raster  
  
plt.show()  
  
# Can you figure out how to show two plots side by side?
```


```
# Hint - examples in the  
# https://autogis-site.readthedocs.io/en/latest/index.html
```



```
In [29]: # Can you figure out how to show two plots side by side?  
  
fig, (ax1, ax2) = plt.subplots(1, 2, figsize=(20, 10)) # 1 row, 2 columns  
  
# Show the slope raster in the first subplot  
show(sloperas, ax=ax1, title="Slope Raster Visualization")
```

```
# Show the trail raster in the second subplot
show(trailras, ax=ax2, title="Trail Raster Visualization")

plt.show()
```




5. Clip the raster to the correct extent:

With rasterio, input layers must match exactly: extent, row and columns, cell size, CRS... in order to overlay

```
In [30]: #Let's try to clip this raster!
#Maybe even both rasters!
#Following the steps from: https://automating-gis-processes.github.io/CSC/notebook
from rasterio.mask import mask
from shapely.geometry import box
import geopandas as gpd
from fiona.crs import from_epsg
```

```
In [32]: show(trailras, cmap='terrain')
```



Out[32]: <Axes: >

```
In [33]: # File path for the shapefile to use for clipping
bnd_shp = r"C:\Users\xfour\Downloads\Lab5c_NewRasters\FedLands_Tetons.shp"

# Turn the shp into a geopandas dataframe
bnd = gpd.read_file(bnd_shp)
```

```
In [34]: # Check that the coordinate systems are the same:
if bnd.crs != sloperas.crs:
    print ("Need to project the vector")
    # Make the vector CRS the same as the raster
    bnd = bnd.to_crs(crs=sloperas.crs.data)
else:
    print ("Coordinate systems are the same "+ str(bnd.crs))
```

Coordinate systems are the same EPSG:26912

So here's what we have:

bnd: This is the geopandas representation of the shapefile we want to clip by

sloperas and distras: The two rasters that we want to clip, then overlay


```
In [35]: def getFeatures(gdf):
    """Function to parse features from GeoDataFrame in such a manner that rasterio
    import json
    return [json.loads(gdf.to_json())['features'][1]['geometry']]
    # Indexing in line above retrieves just one feature
```

```
coords = getFeatures(bnd)
# If you print this, be prepared for a few pages of coordinates:
#print (coords)
```

```
In [36]: # Now let's actually do the clip:
# Mask is shown as just "mask" because of the way we imported it. It's really raster
# Refer to https://rasterio.readthedocs.io/en/stable/topics/masking-by-shapefile.ht
out_img, out_transform = mask(sloperas, coords, True)
```

```
In [37]: # Update the metadata for the clipped version:
out_meta= sloperas.meta.copy()
```

```
In [38]: show(out_img)
```




```
Out[38]: <Axes: >
```

```
In [39]: # Save the output as a new TIF:
# Output raster
out_tif = r"C:\Users\xfour\Downloads\Lab5c_NewRasters\slope_clp.tif"
with rasterio.open(out_tif, "w", **out_meta) as dest:
    dest.write(out_img)
```

```
In [40]: # Open the clipped raster file
slope_clp = rasterio.open(out_tif)

# Visualize
show(slope_clp, cmap='terrain')
```



Out[40]: <Axes: >

```
In [43]: slopeval = sloperas.read()
distval = trailras.read()
```

The rest of Lab 5c:

Perform these raster based operations to get additional practice with it:

1. Find and clip another raster to another shapefile
2. Overlay the distance and slope rasters using map algebra: experiment with addition and multiplication to execute both a binary and a weighted overlay situation.
3. Use the RMNP data from Lab 4 /5b to see what you can do with the elevation layer and Zonal Statistics: Average elevation for each lake (or subset of lakes, or just one lake) Add elevation attribute to each Elk point

OR:

--Explore the EarthLab courses and tutorials in Python <https://www.earthdatascience.org/> and pick out a 2-3 topics that interest you (Aim for ~1 hour of time) --Follow the Mosaic lesson from <https://autogis-site.readthedocs.io/en/latest/notebooks/Raster/raster-mosaic.html> using data that you find/download yourself and create a mosaic

```
In [ ]: ### Add new cells here as needed to complete the rest of Lab 5c
```

```
In [46]: # Path to the good distance tif
elevf = r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\RMNPelev.tif"
```

```
elevras = rasterio.open(elevf)
```

```
In [48]: lake_shp = r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\RMNP_Lakes.shp"
lakes = gpd.read_file(lake_shp)
```


```
In [56]: # Check that the coordinate systems are the same:
if lakes.crs != elevras.crs:
    print ("Need to project the vector")
    # Make the vector CRS the same as the raster
    lakes = lakes.to_crs(crs=elevras.crs.data)
else:
    print ("The Coordinate systems are the same: "+ str(lakes.crs))
```

The Coordinate systems are the same: +init=epsg:26913 +type=crs

```
In [53]: def getFeatures(gdf):
    import json
    return [json.loads(gdf.to_json())['features'][1]['geometry']]
coords = getFeatures(lakes)
```

```
In [58]: #Let's try this visualization thing...
from rasterio.plot import show
import os
import matplotlib.pyplot as plt
%matplotlib inline

fig, ax = plt.subplots(figsize=(10, 10)) # Set the size of the figure
show(elevras, ax=ax, title="Elevation Raster Visualization") # Display the raster
plt.show()
```




```
In [62]: from rasterio.mask import mask
```

```
In [89]: lakes_geom = lakes.geometry.values # Extract the geometry in a format suitable for
out_image, out_transform = mask(elevras, lakes_geom, crop=True)
clipped_ras = rasterio.open('clipped_raster.tif', 'w', driver='GTiff',
                           height=out_image.shape[1],
                           width=out_image.shape[2],
                           count=1,
                           dtype=out_image.dtype,
                           crs=elevras.crs,
                           transform=out_transform)
clipped_ras.write(out_image[0], 1)
clipped_ras.close()
```


```
In [90]: with rasterio.open('clipped_raster.tif') as src:
    # Read the first and only band
    image = src.read(1)
```

```
# Setup the figure and axes
plt.figure(figsize=(10, 10))

# Show the image, using a colormap and a color bar
plt.imshow(image, cmap='viridis') # You can change 'viridis' to other colormap
plt.colorbar(label='Elevation (meters)') # Adjust Label as appropriate
plt.title('Clipped Elevation Map of Lakes')
plt.xlabel('Pixel X Coordinates')
plt.ylabel('Pixel Y Coordinates')
plt.show()
```



```
In [68]: import contextily as ctx
fig, ax = plt.subplots(figsize=(10, 10))
lakes.plot(ax=ax, alpha=0.5, color='blue')
ctx.add_basemap(ax, crs=lakes.crs.to_string())
ax.set_title('Lake Locations in RMNP with Basemap')
plt.show()
```



In [69]: `pip install rasterstats`

```
Collecting rasterstats
  Downloading rasterstats-0.19.0-py3-none-any.whl.metadata (4.1 kB)
Requirement already satisfied: affine in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (2.4.0)
Requirement already satisfied: click>7.1 in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (8.1.7)
Requirement already satisfied: cligj>=0.4 in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (0.7.2)
Requirement already satisfied: fiona in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (1.9.5)
Requirement already satisfied: numpy>=1.9 in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (1.26.4)
Requirement already satisfied: rasterio>=1.0 in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (1.3.10)
Collecting simplejson (from rasterstats)
  Downloading simplejson-3.19.2-cp311-cp311-win_amd64.whl.metadata (3.2 kB)
Requirement already satisfied: shapely in c:\users\xfour\anaconda3\lib\site-packages (from rasterstats) (2.0.1)
Requirement already satisfied: colorama in c:\users\xfour\anaconda3\lib\site-packages (from click>7.1->rasterstats) (0.4.6)
Requirement already satisfied: attrs in c:\users\xfour\anaconda3\lib\site-packages (from rasterio>=1.0->rasterstats) (23.1.0)
Requirement already satisfied: certifi in c:\users\xfour\anaconda3\lib\site-packages (from rasterio>=1.0->rasterstats) (2024.2.2)
Requirement already satisfied: snuggs>=1.4.1 in c:\users\xfour\anaconda3\lib\site-packages (from rasterio>=1.0->rasterstats) (1.4.7)
Requirement already satisfied: click-plugins in c:\users\xfour\anaconda3\lib\site-packages (from rasterio>=1.0->rasterstats) (1.1.1)
Requirement already satisfied: setuptools in c:\users\xfour\anaconda3\lib\site-packages (from rasterio>=1.0->rasterstats) (68.2.2)
Requirement already satisfied: six in c:\users\xfour\anaconda3\lib\site-packages (from fiona->rasterstats) (1.16.0)
Requirement already satisfied: pyparsing>=2.1.6 in c:\users\xfour\anaconda3\lib\site-packages (from snuggs>=1.4.1->rasterio>=1.0->rasterstats) (3.0.9)
Downloading rasterstats-0.19.0-py3-none-any.whl (16 kB)
Downloading simplejson-3.19.2-cp311-cp311-win_amd64.whl (75 kB)
----- 0.0/75.3 kB ? eta -:-:-
----- 75.3/75.3 kB 2.0 MB/s eta 0:00:00
Installing collected packages: simplejson, rasterstats
Successfully installed rasterstats-0.19.0 simplejson-3.19.2
Note: you may need to restart the kernel to use updated packages.
```

```
In [71]: from rasterstats import zonal_stats
```

```
In [72]: lake_shp = r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\RMNP_Lakes.shp
lakes = gpd.read_file(lake_shp)
elevf = r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\RMNPElev.tif"

# Calculate zonal statistics
stats = zonal_stats(lakes, elevf, stats="mean")

# Add the average elevation to the Lakes GeoDataFrame
lakes['avg_elevation'] = [stat['mean'] for stat in stats]
```

```
# Now you can view the updated GeoDataFrame
print(lakes[['avg_elevation']])
```

```
avg_elevation
0           NaN
1    3515.000000
2    3474.000000
3    3472.250000
4           NaN
..
730      3364.000000
731      3377.000000
732           NaN
733           NaN
734    3404.333333
```

```
[735 rows x 1 columns]
```

```
In [77]: elk_shp = r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\Elk843cow.shp"
elk = gpd.read_file(elk_shp)
```

```
# Open the elevation raster
with rasterio.open(elevf) as elev_ras:
    # Extracting coordinates and transforming them into the raster's coordinate system
    # if necessary (though both should be in the same CRS)
    elk['elevation'] = [list(elev_ras.sample([(geom.x, geom.y)]))[0][0] for geom in elk]

# View the result to ensure it's correct
print(elk[['elevation']])
```

```
elevation
0    32767
1    32767
2    32767
3    32767
4    32767
..
422   32767
423   32767
424   32767
425   32767
426   32767
```

```
[427 rows x 1 columns]
```

```
In [87]: lakes.to_file(r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\LakesE1.shp")
elk.to_file(r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\Elk843E1.shp")
```

```
C:\Users\xfour\AppData\Local\Temp\ipykernel_12668\2084059619.py:1: UserWarning: Column names longer than 10 characters will be truncated when saved to ESRI Shapefile.
  lakes.to_file(r"C:\Users\xfour\Downloads\RMNPDataLesson4\RMNPDataLesson4\LakesE1.shp")
```